

## **CLEANING & CARE INSTRUCTIONS**

Most of Byrne's accessories (power/data centers) have a metal, powder coat, or plastic finish. These surfaces should be cleaned by simply dampening a soft cloth with warm water, and gently dabbing any affected areas. For heavily affected areas, apply soap in moderation. Avoid aggressive chemical solvents (i.e. bleach and acidic or alkaline solutions). Plastic cords & plugs should be dry dusted regularly.

If further disinfecting is desired, we suggest using a PH neutral disinfectant, such as diluted solutions of either hydrogen peroxide, isopropyl alcohol, or off the shelf products such as OXIVIR TB or Clorox Healthcare Bleach Germicidal. Clorox wipes may also be used when used as directed (wipe off non-porous surface and let air dry) and then re-wipe down with clean water and a clean cloth. Any cleaner that is used should be applied to a soft cloth or disposable wipe following the manufacturer's directions; do not apply directly to the Byrne product.

For more information, or questions, please contact Byrne Customer Relations at 800.999.3567